

## SELECTION AND INSTALLATION INSTRUCTIONS

### 9" to 10" Vent Transition

### gas-fired unit heaters model PD/BD 300

#### **IMPORTANT**

The use of this manual is specifically intended for a qualified installation and service agency. All installation and service of these units must be performed by a qualified installation and service agency. Modine manuals may contain excerpts from component supplier literature adapted for Modine products. Any accompanying component supplier literature is for general information.

A vent transition is now offered which accommodates a connection from a 9" flue collar to a 10" vent system. The transition can be utilized in replacement applications where 10" vent is already installed. It is also useful in specific areas where 9" vent materials are not readily available.

To install vent transition, place oval end of transition (refer to Figure 1.1) around outside of unit heaters flue collar. Once it has been satisfactorily secured, place the 10" vent pipe onto the round end (refer to Figure 1.1) of transition piece. Secure as needed. Ensure that installation is in accordance with installation manual 6-553, latest revision.

Figure 1.1  
9" to 10" Vent Transition



THIS MANUAL IS THE PROPERTY OF THE OWNER.  
PLEASE BE SURE TO LEAVE IT WITH THE OWNER WHEN YOU LEAVE THE JOB.